



INSTALLATION MANUAL


38120N/V



230V | SMD LED | CCT V | 18W PV | IP65 | PC
Complete with PV driver / Stainless steel clips.




CCT VARIABLE
SWITCH



Power Selection (On Driver)

	1	2
ON	10W 200mA	<input type="radio"/>
●	<input type="radio"/>	13W 250mA
■	15W 300mA	<input type="radio"/>
□	<input type="radio"/>	18W 350mA
○	●	●



Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.

www.1-light.eu