

INSTALLATION MANUAL

65042T


ecotrackspot



80
CRI

42W | SMD 2835 | 100-240V | 50/60Hz | IP20 | Die cast | Adjustable

Complete with driver.



<p>1</p> <p>To mount the track adaptor into the track system, check that both tabs A & B on the adaptor are in the “open” position and insert into the track.</p>	<p>2</p> <p>Ensure the track adaptor is inserted with the correct orientation.</p>	<p>3</p> <p>Rotate tab A clockwise 90° to connect the adaptor to the neutral circuit.</p>
<p>4</p> <p>Rotate tab B to the desired position circuit.</p>	<p>4a</p> <p>Unconnected: The luminaire is fixed to the track but not connected to any circuit.</p>	<p>4b</p> <p>Circuit 1: To connect to circuit 1, from the starting position, rotate the tab B clockwise 90°.</p>
<p>4c</p> <p>Circuit 2: To connect to circuit 2, from the starting position, rotate the tab B anti-clockwise 90°.</p>	<p>4d</p> <p>Circuit 3: To connect to circuit 3, from the starting position, pull the tab B down and rotate anti-clockwise 90°.</p>	

Warnings:

1. Make sure that the product is installed properly before connecting to electricity.
2. Do not cover the fitting.
3. Maintenance and installation should only be carried out by a professional electrician.